



when you don't use the rotary device ,
please take off the motor of the rotary device ,
and keep the on-off is off .
when you use the rotary device ,
then put in the motor of rotary device ,
then keep the on-off is on